



F150 Drawer System

Parts & Instructions

SKU#7126-7654

Parts List:

- (2) Key
- (2) Leveling Feet
- (3) Bolts
- (9) Nuts
- (6) Washers

Instructions:

- 1) Remove OEM plastic rail (if needed).
- 2) Start on driver side.
- 3) Put (1) bolt through the middle hole in the seat bracket. Add (1) nut to hold in place.
- 4) Add second nut to bolt and then the washer.
- 5) Repeat on the next seat bracket in the middle.
- 6) Remove the drawer from the box by pressing the side clips on the rails. Set drawer to the side.
- 7) Add Leveling Feet under the front portion of the box shell.
- 8) Slide box into the truck and line up the holes with the bolts.
- 9) Add (1) to each bolt from the inside of the box. Note: the nut on the inside of the bolt should only be tightened down so that the nut and the end of the bolt are flush. If there is too much thread of the bolt passed the nut, the drawer will have trouble closing.
- 10) Adjust the nut on the outside to align everything.
- 11) Bring in the drawer and lay in front of the box.
- 12) Pull out the slides slightly and line up rails and carefully insert drawer.
- 13) Make sure the box is even and drawer slides smooth.
- 14) Load it up and you're good to go.



F150 Drawer System

Parts & Instructions

SKU#7126-7654

1. Remove OEM Plastic Rail (if needed)



2. Starting on Driver Side. 4. Put (1) bolt through the middle hole in the seat bracket. Add (1) nut to hold in place. 4. Add second nut to bolt and then the washer. 5. Repeat on the next seat bracket in the middle





F150 Drawer System

Parts & Instructions

SKU#7126-7654

6. Remove the drawer from the box by pressing the side clips on the rails. Set drawer to the side.



7. Add Leveling Feet under the front portion of the box shell.
8. Slide box into the truck and line up the holes with the bolts.





F150 Drawer System

Parts & Instructions

SKU#7126-7654

9. Add (1) to each bolt from the inside of the box. Note: the nut on the inside of the bolt should only be tightened down so that the nut and the end of the bolt are flush. If there is too much thread of the bolt passed the nut, the drawer will have trouble closing.
10. Adjust the nut on the outside to align everything.
11. Bring in the drawer and lay in front of the box.
12. Pull out the slides slightly and line up rails and carefully insert drawer.
13. Make sure the box is even and drawer slides smooth.
14. Load it up and you're good to go.

